### Types of Examinations

Per Section XI of the ASME Boiler and Pressure Vessel Code (Rules for In-service Inspection of Nuclear Power Plant Components), there are three types of examinations used during an in-service inspection:

Visual Surface Volumetric

#### **Visual Examination**

**Definition:** A nondestructive examination method used to evaluate an item by observation.

- Used to determine the surface condition of an article, alignment of mating surfaces, compliance with physical requirements (dimensions, settings), etc.
- Usually the first method employed for locating suspected defects
- Also the oldest and most commonly used NDT method

#### Why Visual Examination?

- Can be used to inspect for surface-breaking discontinuities:
  - Cracks
  - Holes
  - Corrosion
- Does not require special equipment other than good eyesight (optical and mechanical aids optional to improve inspection quality)
- Low cost

### **Surface/Volumetric Examinations**

- Surface examinations indicate the presence of discontinuities on the surface of an article
  - Typical inspection methods: liquid penetrant, magnetic particle, eddy current
- Volumetric examinations indicate the presence of discontinuities throughout the volume of the article
  - May be conducted from either the inside or outside of the component
  - Typical inspection methods: radiography, ultrasonic testing, eddy current (for thin tubing or plates)

### **Some Key Terminology**

- Specification
- Procedure
- Standard
- Regulation
- Code

### **Specification vs. Procedure**

- Specification: An explicit set of requirements to be satisfied by a material, product, or service.
  - If a material, product or service fails to meet one or more of the applicable specifications, it may be referred to as being out of specification (OOS)
- **Procedure:** Standardized and documented process for performing an experiment or conducting an evaluation.

#### Standard – Two Definitions

- 1) Artifact that serves as a basis for comparison; a reference against which other things can be evaluated or calibrated.
- A set of technical definitions and guidelines that function as instructions for designers, manufacturers, operators, or users of equipment.

### Regulation Vs. Code

 Regulation: A principle, rule, or law designed to control or govern behavior.

#### • Code:

- 1) A systematic collection of regulations and rules of procedure or conduct.
- 2) A standard that has been adopted by one or more governmental bodies and is enforceable by law, or when it has been incorporated into a business contract.
  - Example: ASME Boiler & Pressure Vessel Code

### **More Common Terminology**

- Discontinuity an interruption in the normal physical structure of an article (ex. cracks, seams, porosity)
- Defect a discontinuity that interferes with the usefulness of the article

All defects are discontinuities, but not all discontinuities are defects!!

### **More Terminology**

- Relevant Condition a condition that requires supplemental examination, corrective measure, or analytical evaluation
- Evaluation the process of determining the significance of examination results through the comparison of those results with applicable acceptance criteria
  - to determine whether an article is acceptable, salvageable (can be repaired), or rejectable
  - Is a "small" imperfection acceptable?

#### VT-1, VT-2, VT-3

- VT-1: Exams conducted to detect discontinuities on the surface of components ("specific exam")
- VT-2: Exams conducted to detect evidence of leakage from pressure retaining components (tanks, pipes, etc.)
- VT-3: Exams conducted to determine the general mechanical and structural condition of components and their supports ("general exam")
  - ➤ Verification of clearances and settings
  - ➤ Inspection for loose or missing parts

### **Inspection Requirements**

Usually requires a written procedure that outlines the following:

- Type of exam to be performed (VT-1 or VT-3)
- Illumination requirements (ex. 50 foot-candles)
  - 1 foot candle is equal to the amount of light given off by a standard candle at a distance of 1 foot
- Surface preparation requirements
- Acceptance criteria
- Inspection interval (how often inspection must occur)
- Required test documentation

#### **Direct vs. Remote**

- Direct visual exams usually occur within 24" of the surface to be examined
  - may use mirrors or magnifying lenses
- Remote visual exams performed in areas that are inaccessible for direct examination (inside of pipes and tanks or in hazardous or radioactive areas)

### **Optical Aids**

- Used when direct visual examination is not possible
  - Microscopes
  - Borescopes
  - Fiberscopes
  - Video Cameras

#### **Mechanical Aids**

- Micrometers
- Calipers
- Depth gauges
- Thread pitch gauges
- Feeler gauges
- Weld gauges

### **Certification Requirements**

 Per ASNT Recommended Practice No. SNT-TC-1A, 2011 edition:

Certification Level	High School Graduate or Equivalent (hrs)	Two Years of Engineering or Technical School (hrs)	Experience Level (hours)
I	8	4	70
II	16	8	140
Totals:	24	12	210

- Level I Trainee
- Level II More experienced
- Level III Highest certification

### **Certification Requirements, Continued**

- Must also pass annual eye exams for:
  - 1) Near vision acuity (sharpness of vision) Jaeger chart
  - 2) Far vision acuity Snellen chart
  - 3) Color vision Ishihara

### Jaeger chart

Near vision acuity is addressed in NDT certification standards and one of the most common means to measure near vision acuity for NDT personnel in the U.S. is to have them read text from a standardized reading card called the Jaeger chart.

#### No. 7.

able treaty, the restitution of the standards and prisoners which had been taken in the defeat of Crassus. His generals, in the early part of his reign, attempted the reduction of Ethiopia and Arabia Felix. They marched near a thou-

#### No. 8. 1.75M

sand miles to the south of the tropic; but the heat of the climate soon repelled the invaders, and protected the unwarlike natives of those sequestered regions

#### No. 9. 2.00M

The northern countries of Europe scarcely deserved the expense and labor of conquest. The forests and morasses of Germany were

#### No. 10

filled with a hardy race of barbarians who despised life when it was separated from freedom; and though, on the first


#### No. 11.

attack, they seemed to yield to the weight of the Roman power, they soon, by a signal

GRAHAM-FIELD

#### **Snellen chart**

The so-called "Snellen chart" is an eye chart that is used to measure visual acuity, or how well somebody sees.
The Snellen chart is the most prevalent eye chart



#### Ishihara test

The **Ishihara test** is a color perception test for red-green color deficiencies. The test consists of a number of colored plates, called Ishihara plates, each of which contains a circle of dots appearing randomized in color and size. Within the pattern are dots which form a number or shape clearly visible to those with normal color vision, and invisible, or difficult to see, to those with a red-green color vision defect, or the other way around.

